


MODEL W1B1664



SPOTNAILS®

Division of Peace Industries, LTD.

1100 Hicks Road, Rolling Meadows, IL 60008
P: 800-873-2239 / 847-259-1620 • F: 888-369-2588
customerservice@spotnails.com
www.spotnails.biz • www.spotnails.com

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24713	Cap Screw - 4PCS	32	P-15194	Valve Seal
02	P-32211	Flat Washer - 4PCS	33	P-18283	Spring
03	P-70062	Exhaust Deflector	◆ 05	P-64390	O-Ring
04	P-60227	Cap	34	P-22232	Plunger
◆ 05	P-15193	Exhaust Seal	35	P-22166	Valve Housing
◆ 06	P-64384	O-Ring	36	P-64391	O-Ring
07	P-18331	Poppet Spring	37	P-18267	Spring
◆ 08	P-64385	Poppet O-Ring	38	AS-21039	Selectable Trigger (Blue)
09	P-63038	Poppet	39	AS-53108	Safety Assembly
◆ 10	P-64233	Piston Stop O-Ring	40	P-96122	No-Mar Tip - 2PCS
◆ 11	P-64386	Cylinder Seal O-Ring	41	P-24358	Screw - 2PCS
12	P-03070	Guide Spacer	42	P-04040	Latch Assembly
◆ 13	P-62097	Gasket - 2PCS	43	P-07297	Roll Pin
14	P-05140	Cylinder	44	AS-10047	Front Plate Assembly
◆ 15	P-64387	Cylinder O-Ring	45	P-08528	Wear Plate
◆ 16	P-64242	O-Ring	46	P-12605	Magazine
17	P-05136	Cylinder Guide	47	P-24430	Screw - 3PCS
◆ 18	P-64633	Cylinder Guide O-Ring	48	P-32170	Washer - 5PCS
◆ 19	P-64388	Piston O-Ring	49	P-12606	Magazine Cover
20	AS-06131	Piston & Driver Assembly	50	P-24308	Screw - 2PCS
21	P-06310	Driver Blade	51	P-24312	Screw
22	P-15195	Bumper	52	P-13146	Bracket
23	P-01313	Body	53	P-26126	Nut - 4PCS
24	P-64389	O-Ring	54	AS-09048	Pusher Assembly
25	P-60175	End Cap	55	P-18482	Spring
◆ 26	P-64240	O-Ring	56	P-24490	Shoulder Screw
27	P-07327	Trigger Pin	57	P-18338	Spring Retainer
28	P-07262	Pin	58	P-18478	Negator Spring
29	P-15157	Return Seal	59	P-03140	Body Spacer
30	P-53165	Safety Guide	60	AS-53117	Safety Pin Kit
31	P-18328	Spring	◆ Parts Included In AS-97493 O-Ring And Seal Kit		

ACCESSORIES (NOT INCLUDED)

52	AS-21040	Sequential Trigger (Red)			
----	----------	--------------------------	--	--	--