


MODEL XBA1564

SPOTNAILS®

Division of Peace Industries, LTD.

1100 Hicks Road, Rolling Meadows, IL 60008
 P: 800-873-2239 / 847-259-1620 • F: 888-369-2588
 customerservice@spotnails.com
 www.spotnails.biz • www.spotnails.com



Ref No.	Part No.	Description	Ref No.	Part No.	Description		
01	P-24370	Screw	39	P-07327	Trigger Pin		
02	P-96118	Bushing	◆	40	P-64240	O-Ring	
03	P-70041	Exhaust Deflector	41	AS-21008	Contact Trigger (Black)(Bump Fire)		
04	P-64377	O-Ring	◆	42	P-64328	O-Ring	
05	P-24456	Cap Screw - 4PCS	44	AS-22037	Plunger w/Housing Assembly		
06	P-32211	Flat Washer - 4PCS	◆	45	P-64383	Plunger O-Ring - 2PCS	
07	P-60172	Cap	46	P-18227	Spring		
08	P-15187	Exhaust Seal	◆	47	P-64336	O-Ring	
◆	09	P-64378	O-Ring	48	P-22145	Pilot Valve	
10	P-18327	Poppet Spring	◆	49	P-64335	O-Ring	
◆	11	P-64028	Poppet O-Ring	◆	50	P-64334	O-Ring
12	P-63037	Poppet	◆	51	P-64333	O-Ring	
◆	13	P-64379	Piston Stop O-Ring	52	P-22144	Trigger Valve Cap	
◆	14	P-64380	Cylinder Seal O-Ring	◆	53	P-64332	Valve Housing O-Ring
15	P-03079	Guide Spacer	54	P-24300	Screw - 2PCS		
◆	16	P-62070	Gasket - 2PCS	55	P-24433	Screw - 2PCS	
17	P-03073	Body Spacer	56	P-32170	Washer - 6PCS		
◆	18	P-64228	Piston O-Ring	57	P-13074	Bracket	
19	AS-06046	Piston & Driver Assembly	58	P-26142	Nut - 6PCS		
◆	20	P-64330	Cylinder O-Ring	59	P-24353	Screw - 3PCS	
21	P-05105	Cylinder	60	P-12418	Magazine Cover		
◆	22	P-64419	O-Ring	61	P-12419	Magazine	
23	P-15188	Bumper	62	P-27182	Wear Insert		
24	P-01267	Body	63	AS-09049	Pusher Assembly		
25	P-64312	O-Ring	64	P-18478	Negator Spring		
26	P-60156	End Cap	65	P-18338	Spring Retainer		
◆	27	P-15201	Return Seal	67	P-06232	Driver Blade	
28	P-07262	Pin	68	AS-21019	Sequential Trigger (Red)		
29	P-53165	Safety Guide	69	P-18267	Spring		
30	P-18328	Spring	70	AS-04040	Latch Assembly		
31	AS-53048	Safety Assembly	71	P-07297	Pin		
32	P-03074	Spacer	72	P-18482	Spring		
33	P-53170	Lower Safety	73	P-24490	Shoulder Screw		
34	P-26125	Nut - 2PCS	74	AS-22041	Plunger w/O-Rings Assembly		
35	P-08473	Wear Plate	75	P-22233	Valve Housing		
36	P-18339	Spring	76	AS-22043	Trigger Valve Assy.		
37	AS-10048	Front Plate Assembly	77	AS-53114	Safety Pin Kit		
38	P-24358	Screw - 2PCS					

◆ Parts Included In AS- 97288 O-Ring And Seal Kit

ACCESSORIES (NOT INCLUDED)

66	P-97454	Air Filter			
----	---------	------------	--	--	--