

W1B1664

16GA BRAD NAILER



Air Pressure: 80-110 PSI

Max Air Pressure: 120 PSI

Air Fitting Size: 1/4" NPT

Loading

- Pull the magazine pusher back until locked.
- Load the fastener strips.
Magazine Capacity: 150 fasteners.
- Push the button to unlock the pusher and slowly move it forward.



Actuation Modes


Selectable Actuation Trigger

Sequential Trigger (Restrictive) available (AS-21040)

Turn the red button to switch the firing mode.

1. Full Sequential Actuation
(Factory Preset)

2. Contact Actuation
(Bump Fire)



Depth Adjustment

- Turn the wheel clockwise to reduce the penetration (as shown).
- Turn the wheel counterclockwise for deeper penetration (as shown).
- Reducing or increasing the air pressure can also affect the depth of the drive.

